



# Triple Crown Modular WaterFed® Pole

Effective November 2024



---

## Getting Started With Your Pole Operation and Maintenance Manual

---

## Overview

Congratulations on your purchase.

Thank you for selecting a Triple Crown Modular WaterFed® Pole. Built with high quality materials and featuring industry leading technology, we are sure that you'll enjoy your new pole. This guide will run you through the basic dos and don'ts of your pole along with instructions for setting it up out of the box.

### CAUTION



**DO NOT  
USE NEAR  
ELECTRICITY!**

### CAUTION



**DO NOT  
STEP ON  
SECTIONS!**

### CAUTION



**DO NOT  
DROP POLE!**

## In The Box

### Parts Check

- Triple Crown Modular WaterFed® Pole
- Brush
- Pole Tubing w/ Pole Connector
- Double Plastic Angle Adaptor
- Shut-Off Valve
- PTFE Lubricant
- End Plug
- Pole Bag

### 1. Unpacking/Inspecting The Pole

Carefully remove the packaging material from around your pole and discard. Examine all collars and sections to make sure that nothing was damaged in shipping. If damage has occurred, notify abc Window Cleaning Supply within 48 hours.

## 2. Initial Setup

You can watch the video at:  
[www.abcWindowSupply.com/ModularGuide](http://www.abcWindowSupply.com/ModularGuide)



1. Separate all sections. Some may be stored inside of each other.
2. Screw double angle adaptor onto the end of your number one section.
3. Screw brush onto the euro threaded side of your double angle adaptor.
4. Assemble sections in order (section 1 to section 2, section 2 to section 3, etc.). Use light coat of PTFE spray on each connection before every use.
5. Insert End Plug into the last section you are using to protect the pole end.
6. Insert pole tubing into desired fitting on your brush. We suggest that you run your tubing externally.

## 3. Replacement Parts

Edge™ 260 DuPont® Brush - EDGE-260-DUPONT  
 Double Angle Adaptor - TCSWITCH  
 Tip - 6000-G-1Tip  
 #1 Section Collar - 6000-G-RC1  
 Bag - 5000-BAG  
 End Plug - 5000-PLUG  
 PTFE Can - 5000-PTFE  
 Section - 5000-[x]-RS  
 Shut-Off Valve - WF601311  
 Tubing - WF600600-[x]

### Optional Accessories

Carbon Gooseneck - 6000-G-GN[x]-CF

